



LE756_C502C-X_1114-V03

		Spare part number	Spare part number	Spare part number	Colours available
1	Cover		90713		62, 127
2	Seat				
3	Bowl				
4	Screw				
5	Sticker control knob		90701		62, 127
6	Control PCB		<i>C-model</i>	90709	127
7	Control knob			<i>X-model</i>	
8	Cosmetic cover straight Cosmetic cover curved				
9	Water level sensor <i>X-model only</i>	90702			
10	Bench welded				
11	Cap waterfill funnel	16848			16
12	Waterfill funnel		90710	90719	
13	O-ring		<i>waterfill funnel</i>	<i>waterfill funnel</i>	
14	Waterfill elbow				
15	O-ring		<i>150mm</i>	<i>180mm</i>	
16	Tube PVC				
17	Drain connector				
18	Sight tube				
19	Clip sight tube	90711			
20	Drain tube		90703		
21	Tunnel				
22	Screw				
23	Base				
24	Pocket cover				
25	PCB cover				
26	Main PCB	90704 <i>C-model</i>	90712 <i>X-model</i>		
27	Retaining plate				
28	Magnet				
29	Magnet basket				
30	Flange lock				
31	Bushing				
32	Saddle				
33	Spring		51802		
34	Bracket				
35	Shaft				
36	Link				
37	Drain plug				
38	O-ring				
39	Blind plug water fill				
40	Pump	90714			
41	Water supply tube				
42	Nozzle		90705		127
43	O-ring				
44	Wiring harness				



LE757_C503L_0215-V02

	Spare part number	Spare part number	Colours available
1	Cover		
2	Seat	90713	62, 127
3	Bowl		
4	Screw		
5	Sticker control knob		
6	Control PCB	90715	62, 127
7	Control knob		
8	Cosmetic cover straight Cosmetic cover curved		
9	Bench welded		
10	Base		
11	Tunnel		
12	Screw		
13	Pocket cover		
14	PCB cover		
15	Main PCB	90716	
16	Retaining plate		
17	Magnet		
18	Magnet basket		
19	Flange lock		
20	Screw		
21	Bushing		
22	Saddle		
23	Spring	51802	
24	Bracket		
25	Shaft		
26	Link		
27	Wire harness		
28	Water supply tube		
29	Hose clamp	90717	
30	Solenoid valve		
31	O-ring	90718	
32	Nozzle		
33	Water supply tube		
34	Water supply tube		
35	Bracket		
36	Screw		
37	Vacuum breaker	16833	
38	Screw		



LE758_C500-WHT_1114-V02

		Spare part number	Spare part number	Spare part number	Colours available
1	Sliding cover	32301			06
2	Blade opener	32300	32331 <i>mechanism right</i>	32332 <i>mechanism left</i>	06
3	Washer				
4	Seal parker				
5	Mechanism retainer				
6	Holding tank plate Left hand version				
6A	Holding tank plate Right hand version				
7	Seal mechanism				
8	Lip seal				
9	Seal plate				
10	Screw				
11	Blade	50731			
12	Bearing	90706			
13	Blade arm				
14	Bushing				
15	Screw				
16	Blade driver				
17	Support track				
18	Screw				
19	Retainer				
20	Magnet				
21	Float arm				
22	Upper automatic vent	23722			06
23	Seal				
24	Foam				
25	Pour out spout		32306		06
26	Measuring cup	25810			16
27	O-ring				
28	Pull handle		51805		16
29	Pull handle bushing right				
30	Pull handle bushing left				
31	Spring				
32	Waste-holding tank complete		90707 <i>right hand version</i>	90708 <i>left hand version</i>	06
33	Tank lock clip	51801			16
34	Wheel		32308		06
35	Wheel bearing right				
36	Wheel bearing left				
37	Wheel bracket				
38	Vent seal		32307		16
39	Spring				
40	Vent button				

		Spare part number	Spare part number	Spare part number	Colours available
41	Handle				
42	Screw				
43	Handle cover				

