


LE914_Portia Potti Qube 145-165

		Spare part number	Spare part number	Colours available
1	Cover		92903	66, 68, 111, 130, 133
2	Seat			
3	Water fill cap	92905		66, 68, 111, 130, 133
4	Flush-water tank			
5	Spring			
6	Clasp			
7	Clasp spacer			
8	Screw			
9	Pour out spout		92907	07, 38, 74, 132
10	O-ring			
11	Seal	92906		111
12	Cap pour out spout			
13	Vent seal	07102		
14	Vent button		92407	111
15	Spring			
16	Vent button seal			
17	Clip			
18	Waste-holding tank			
19	Cover valve handle			
20	Spring valve handle			
21	Valve handle			
22	Screw			
23	Float retainer			
24	Float arm			
25	Foam			
26	Bushing slotted			
27	Boot seal			
28	Retainer blade			
29	Blade			
30	Lipseal	07101		
31	Bellow	07862		62
32	Tubing			
33	Check valve body/flapper			
34	Flush tube			
35	Nozzle			
36	O-ring			
37	Spring/plunger			



LE915_Portia Potti Qube 335-345-365_0514-V01

		Spare part number	Spare part number	Spare part number	Colours available
1	Cover		92904	92903	66, 68, 111, 130, 133
2	Seat		PPQ335	PPQ345-365	
3	Water fill cap	92905			66, 68, 111, 130, 133
4	Flush-water tank				
5	Spring				
6	Clasp				
7	Clasp spacer				
8	Screw				
9	Pour out spout			92907	07, 38, 74, 132
10	O-ring				
11	Seal		92906		111
12	Cap pour out spout				
13	Vent seal	07102			
14	Vent button		92407		111
15	Spring				
16	Vent button seal				
17	Clip				
18	Waste-holding tank				
19	Cover level indicator		92909 PPQ335	92908 PPQ345-365	07, 38, 74, 76, 132
20	Side glass level indicator				
21	Magnet				
22	Dial				
23	Cover valve handle				
24	Spring valve handle				
25	Valve handle				
26	Screw				
27	Float retainer				
28	Float arm				
29	Foam				
30	Bushing slotted				
31	Boot seal				
32	Retainer blade				
33	Blade				
34	Lipseal	07101			
35	Piston pump	92921 PPQ335	92901 PPQ345-365		66, 111, 130
36	Flush tube				
37	Nozzle				
38	O-ring				
39	Spring/plunger				